


AD-A188 021


ADDASET (AIR DEFENSE DIGITAL AVIONICS SEEKER  
ENHANCEMENT TECHNOLOGY) EVAL. (U) ALABAMA UNIV IN  
HUNTSVILLE SCHOOL OF ENGINEERING P L RONTINE ET AL  
05 JAN 87 UAH-5-32329 ANSMI-CR-RD-SS-86-4 F/G 16/4 2

1/1

UNCLASSIFIED

NL





MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A

AD-A180 021



TECHNICAL REPORT CR-RD-SS-86-4

ADDASET EVALUATION/CALIBRATION SUPPORT


Prepared By:

Peter L. Romine  
Timothy A. Palmer  
Terry N. Long  
School of Engineering  
The University of Alabama in Huntsville  
Huntsville, AL 35899

Prepared For:

Systems Simulation and Development Directorate  
Research, Development, and Engineering Center  
US Army MICOM

JANUARY 1987



**U.S. ARMY MISSILE COMMAND**

*Redstone Arsenal, Alabama 35898-5000*

DTIC  
ELECTE  
S MAY 01 1987 D  
CED

Cleared for public release; distribution is unlimited.

#### **DISPOSITION INSTRUCTIONS**

**DESTROY THIS REPORT WHEN IT IS NO LONGER NEEDED. DO NOT  
RETURN IT TO THE ORIGINATOR.**

#### **DISCLAIMER**

**THE FINDINGS IN THIS REPORT ARE NOT TO BE CONSTRUED AS AN  
OFFICIAL DEPARTMENT OF THE ARMY POSITION UNLESS SO DESIGNATED  
BY OTHER AUTHORIZED DOCUMENTS.**

#### **TRADE NAMES**

**USE OF TRADE NAMES OR MANUFACTURERS IN THIS REPORT DOES  
NOT CONSTITUTE AN OFFICIAL INDORSEMENT OR APPROVAL OF  
THE USE OF SUCH COMMERCIAL HARDWARE OR SOFTWARE.**

AD-A180021

REPORT DOCUMENTATION PAGE

Form Approved  
OMB No 0704-0188  
Exp. Date Jun 30, 1986

1a. REPORT SECURITY CLASSIFICATION <b>UNCLASSIFIED</b>			1b. RESTRICTIVE MARKINGS		
2a. SECURITY CLASSIFICATION AUTHORITY			3. DISTRIBUTION/AVAILABILITY OF REPORT Cleared for public release; distribution is unlimited.		
2b. DECLASSIFICATION/DOWNGRADING SCHEDULE					
4. PERFORMING ORGANIZATION REPORT NUMBER(S) 5-32329			5. MONITORING ORGANIZATION REPORT NUMBER(S) CR-RD-SS-86-4		
6a. NAME OF PERFORMING ORGANIZATION UAH School of Engineering		6b. OFFICE SYMBOL (if applicable)	7a. NAME OF MONITORING ORGANIZATION Commander, US Army MICOM ATTN: AMSMI-RD-SS-SE		
6c. ADDRESS (City, State, and ZIP Code) The University of Alabama in Huntsville Huntsville, AL 35899			7b. ADDRESS (City, State, and ZIP Code) Redstone Arsenal, AL 35898		
8a. NAME OF FUNDING/SPONSORING ORGANIZATION		8b. OFFICE SYMBOL (if applicable)	9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER DAAH01-82-D-A008		
8c. ADDRESS (City, State, and ZIP Code)			10. SOURCE OF FUNDING NUMBERS		
			PROGRAM ELEMENT NO.	PROJECT NO.	TASK NO.
11. TITLE (Include Security Classification) ADDASET Evaluation/Calibration Support					
12. PERSONAL AUTHOR(S) Peter L. Romine, Timothy A. Palmer, and Terry N. Long					
13a. TYPE OF REPORT Final		13b. TIME COVERED FROM 11/84 TO 5/85		14. DATE OF REPORT (Year, Month, Day) 87/Jan/05	
15. PAGE COUNT 90					
16. SUPPLEMENTARY NOTATION					
17. COSATI CODES			18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number)		
FIELD	GROUP	SUB-GROUP	ADDASET		
			DEBUG		
			Program Listings		
			Seeker		
			User Aids		
19. ABSTRACT (Continue on reverse if necessary and identify by block number)  Verification and calibration software for the Air Defense Digital Avionics Seeker Enhancement Technology (ADDASET) hardware is documented. Software rationale, operation sequence, program listings and user aids are provided.					
20. DISTRIBUTION/AVAILABILITY OF ABSTRACT <input type="checkbox"/> UNCLASSIFIED/UNLIMITED <input type="checkbox"/> SAME AS RPT. <input type="checkbox"/> DTIC USERS			21. ABSTRACT SECURITY CLASSIFICATION <b>UNCLASSIFIED</b>		
22a. NAME OF RESPONSIBLE INDIVIDUAL Dr. M. M. Hallum			22b. TELEPHONE (Include Area Code) 205-876-4141		22c. OFFICE SYMBOL AMSMI-RD-SS

January 1987

**ADDASET EVALUATION/CALIBRATION SUPPORT**

Final Technical Report for Period  
28 November 1984 through 31 May 1985

January 1987

Prepared By:

Peter L. Romine  
Timothy A. Palmer  
Terry N. Long  
School of Engineering  
The University of Alabama in Huntsville  
Huntsville, AL 35899

Prepared For:

Systems Simulation and Development Directorate  
Research, Development, and Engineering Center  
US Army MICOM

Accession For	
NTIS CRA&I	<input checked="checked" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
A-1	



Cleared for public release; distribution is unlimited.

# TABLE OF CONTENTS

	<u>Page</u>
I. INTRODUCTION.....	1
II. DEBUG TEST PROGRAM.....	1
A. Introduction.....	1
B. Discrete I/O Control.....	2
C. Analog I/O Control.....	2
D. Calibrate Analog-Buffer Card.....	2
E. DEBUG Software Notes.....	3
III. ADDITIONAL I/O TEST PROGRAMS.....	3
IV. EVALUATION/CALIBRATION AIDS.....	4
V. CONCLUSIONS AND RECOMMENDATIONS.....	7
APPENDIX A. DEBUG.....	A-1
APPENDIX B. ADDISP.....	B-1
APPENDIX C. DARAMP.....	C-1
APPENDIX D. ADTODA.....	D-1
APPENDIX E. DSCOUT.....	E-1
APPENDIX F. ACTIVITY.....	F-1

## PREFACE

This technical report was prepared by the Research Staff of the Electrical and Computer Engineering Department, School of Engineering, The University of Alabama in Huntsville. The work documented in this report was performed by Terry N. Long, Timothy A. Palmer, and Peter L. Romine. The purpose of this report is to provide documentation of technical work performed and results obtained under delivery order number 0044, contract number DAAH01-82-D-A008. Mr. Terry N. Long was the principal investigator; Dr. M. M. Hallum, III, Chief, Systems Evaluation Branch, was the technical monitor; and Mr. Mark Horton also from the Systems Evaluation Branch of the Systems Simulation and Development Directorate, U.S. Army Missile Command, provided technical coordination.

The technical viewpoints, opinions, and conclusions expressed in this document are those of the authors and do not necessarily express or imply policies or positions of the U.S. Army Missile Command.



## I. INTRODUCTION

A comprehensive test routine was required for verification and calibration of the Air Defense Digital Avionics Seeker Enhancement Technology (ADDASET) hardware built by the Boeing Company. A C-routine, DEBUG, and its supporting routines provide calibration and debug capabilities for the HAWK/ADDASET test bed. The programs were generated using a Zilog System-8000 UNIX-based development system which was chosen for compatibility with the Z8002-based single board computers used in the ADDASET system. Compatibility is such that compiled object modules and executables originating on the System-8000 can be transported directly to the computers in the ADDASET system.

Operation of the DEBUG test program, which is a very versatile multipurpose program, is described in Section II. Additional special purpose routines were developed during the hardware acceptance phase of the ADDASET program and are briefly described in Section III. Several user aids were also developed or identified during the acceptance process, and are described in Section IV. Conclusions and recommendations are presented in Section V.

## II. DEBUG TEST PROGRAM

### A. Introduction

The DEBUG test program is a versatile, multipurpose diagnostic program that can be used for operational verification or calibration of ADDASET hardware. Program execution is initiated after entering "debug". The program is fully menu-driven with the menu illustrated in Table 1 being displayed initially. As shown by the menu, five separate processes can be performed. The desired process can be chosen by the proper selection. Output and input discretes can be controlled as well as analog-to-digital converters (A/D's) and digital-to-analog converters (D/A's). There is also a routine to facilitate calibration of the system's analog buffers.

Discrete I/O control, analog I/O control, and analog buffer card calibration are described below. Additionally, some notes concerning DEBUG software design are provided.

TABLE 1. Opening Menu

- O) Output byte to discrete channel
- I) Input byte from discrete channel
- A) A/D input routine
- D) D/A output routine
- C) Calibrate analog-buffer card
- E) Exit to monitor

Enter selection (O,I,A,D,C,E):

## B. Discrete I/O Control

The ADDASET system currently supports three 8-bit discrete input and three 8-bit discrete output channels. The digital interface is required for monitoring and controlling the four binary signals originating on the missile (Radar Enable, End of Sustain, Pitch Precession, and Antenna Center commands) and the eight software emulated signals (Radar Enable, Head Enable, Elevon Enable, Test Mode, Test Select 1, Test Select 2, Analog Stabilization Loop Closure, and Antenna Center Mode). Each discrete has a corresponding LED indicator on the front panel of the interface rack to display the status of each bit. By selecting the Input/Output byte option from the main menu, the operator can either read discrete input channel A or specify an arbitrary bit pattern for output on a selected channel.

Press "O" or "o" to output a byte on a discrete channel. The system will prompt the user for the channel number (0-2) and the data in hex (0-FF). After entry, the output data is also echoed to the terminal screen.

Press "I" or "i" to input data from discrete channel A. Input data is displayed on the terminal screen and updated continuously. The input operation can be halted at any time by pressing the ESC key on the terminal keyboard.

## C. Analog I/O Control

The A/D and D/A options allow the operator to monitor the voltage at any of 24 analog inputs or specify an arbitrary voltage for output on any of 16 analog outputs. Voltages are displayed on the terminal screen in floating point. Real valued voltages can also be entered at the keyboard for output on a selected analog line.

Press "A" or "a" to convert an external analog voltage signal to digital for display on the terminal screen. The operator is prompted to select an analog input channel (0-23). The voltage is then displayed on the terminal screen and updated continuously until the ESC key is pressed.

Press "D" or "d" to output an arbitrary voltage. The operator is prompted to enter the channel number (0-15) and the output data. Output data can be any real number voltage within the limits of the power supply (+10V). The actual output value is echoed to the terminal after output on the selected channel.

## D. Calibrate Analog-Buffer Card

The analog-buffer card is the analog interface between the missile and the ADDASET rack. The buffer card's primary function is for adjustment of biases and gains associated with each analog I/O line on the interface rack. It also provides protection for missile and rack components. To aid in calibration of the analog-buffer card, the calibration option provides the menu shown in Table 2.

TABLE 2. Analog-Buffer Card Calibration Menu

- G) select ground
- +) select plus(+) voltage
- ) select minus(-) voltage
- D) display A/D channels
- M) main menu

Select ground, plus voltage, and minus voltage options apply the corresponding signal to each of the analog inputs. The converted voltage can then be monitored using the display A/D function. In this configuration, the analog card can be calibrated by adjusting the gains and/or biases on the card until the correct voltage is displayed on the terminal. By pressing "G", "+", or "-", the inputs to the buffer card are either grounded, set to the precision positive calibration voltage, or set to the precision negative calibration voltage.

To monitor a particular channel, press "D" or "d" and input the desired A/D channel number (0-15) when prompted. The voltage presented to the selected channel is displayed on the terminal screen and is updated continuously until the ESC key is pressed. The escape key returns the user to the configuration menu.

Press "M" or "m" to exit the calibration menu and return to the opening menu.

#### E. DEBUG Software Notes

A listing of DEBUG code is presented in Appendix A. Some important pieces of information can be derived from this code. First, the program's menu format can be examined by examining the arguments of the "mess-c" functions. Also, the register addresses for I/O and control functions can be easily found in the code.

A large portion of the code was developed to facilitate manipulation of floating point numbers. Some of the routines are directly callable from C and some are not. It is useful to note that they can be used for a variety of applications.

### III. ADDITIONAL I/O TEST PROGRAMS

DEBUG resulted from the combination of a number of test and calibration programs. Several other routines were developed in addition to those included in DEBUG and they perform a variety of useful functions.

## 1. ADDISP

ADDISP is particularly useful because it provides for the simultaneous display of up to seven of the 23 A/D channels. The user must supply the number of channels to be displayed at one time (1-7, do not choose 0). The user must also supply which ADC (1-23) should be displayed in each column (0-6) of the display. The user can then choose continuous updates (press C), discrete updates (press D), or pause (press P). A listing of ADDISP is provided in Appendix B.

## 2. DARAMP

DARAMP is also very useful as a verification tool. It generates a ramp output to a block of D/A's. The user must supply the start channel and stop channel of the block of D/A's to be exercised as well as the start value and stop value of the ramp. The user must also supply the step size of the ramp input divided by sixteen. Dynamic operation of the D/A's can be examined by using this routine, and each discrete level can be evaluated. A listing of DARAMP is provided in Appendix C.

## 3. ADTODA

ADTODA facilitates simultaneous output to a D/A channel from an A/D channel. This permits operation verification by tying pairs of channels together. A listing of ADTODA is provided in Appendix D.

## 4. DSOUT

DSOUT simply sequences all of the output discretes. The program is marginally useful, and its listing is provided in Appendix E.

## 5. ACTIVITY

ACTIVITY exercises the operation modes. It is marginally useful, and a listing of the program is provided in Appendix F.

## IV. EVALUATION/CALIBRATION AIDS

A detailed review of ADDASET documentation revealed that wiring information exists for all system interfaces. However, the information exists in various forms with no way to easily trace a signal from beginning to end. Figure 1 was developed in an effort to summarize the configuration and to provide a starting point for the wiring documentation. ADDASET/HAWK system elements are identified along with individual connectors. Each connector has been assigned a number, and they are provided in the figure. Additionally, the types of wiring and the numbers of lines have been identified. The most useful characteristic of the figure is the identification of the documentation that corresponds to each interface. The amount of interface documented by each piece of documentation and the set numbers of the corresponding documentation are also noted.




Figure 3. ADDASET WIRING ILLUSTRATION

Table 3. A/D and D/A Scaling

Hex	Volts	Decimal
7FF0	+10	2047
7320	+9	1842
6660	+8	1638
5990	+7	1433
4CC0	+6	1228
3FF0	+5	1023
3330	+4	0819
2660	+3	0614
1990	+2	0409
0CD0	+1	0205
0000	0	0
F330	-1	-0205
E670	-2	-0409
D9A0	-3	-0614
CCD0	-4	-0819
C010	-5	-1023
B340	-6	-1228
A670	-7	-1433
99A0	-8	-1638
8CE0	-9	-1842
8010	-10	-2047

Another verification aid is provided in Table 3. It contains scaling numbers used by the A/D's and D/A's. However, its usefulness may be marginal since scaling is now provided within DEBUG code.

## V. CONCLUSIONS AND RECOMMENDATIONS

The programs and aids described in this report provide a comprehensive means to verify ADDASET hardware operation and provide ADDASET calibration. They have been used in the acceptance testing phase of the ADDASET program and have been used to calibrate the analog components of the system. They have also been used to monitor missile discretes in the various modes of operation.

The C language used for program development has proved to be very advantageous for I/O type activities. Therefore, it is recommended that the language be used for all ADDASET programming which requires user or hardware interfaces.

The System-8000 development system used for program development has presented several difficulties. Consequently, it is recommended for alternative systems to be examined for program development. PC type systems should be carefully considered.

The ADDASET program now has the test bed required to begin the development of digital avionics techniques and the aids required to maintain that test bed. Therefore, the ADDASET program should proceed at a rapid pace.

**APPENDIX A**

**DEBUG**



/\*\*\*\*\*\*

Main program to allow user to modify D/A and output discrettes a  
as monitor A/D and input discrettes.

Functions defined in debug.c module:

main()                    C routine provides for the men  
                          user interface.

Externals ( in\_char,out\_crlf,mess\_c,in\_int,out\_int,da\_out,cio  
            cio\_outa, cio\_outb, cio\_outc, cio\_ina,ad\_in\_a,ad\_  
            fp\_in,fp\_out,fp\_out\_e,fpcon,fpconv,fdiv )

\*\*\*\*\*

```
extern int    in_char(),out_crlf(),in_int(),out_int(),da_out();
extern int    cio_init(),cio_outa(),cio_outb(),cio_outc(),cio_ina();
extern int    ad_in_a(),ad_in_b();
extern int    mess_c();
extern long int fp_in(),fp_out(),fp_out_e(),fpcon(),fpconv(),
               fdiv();
```

```
int          i,j,k,l,chan,data;
int          array[30],*point;
char         c,d,e,go,ok;
long int     con3276p8,long1,long2;
```

```
main () {
    con3276p8 = fpcon("3276.8");

    cio_init(1,4000); /* sets up cio for input to cio2a and output
                       /* ciola,ciolb,ciolc */

    out_crlf(); /* clear a little bit of screen off */
    out_crlf();

    mess_c("General Test Program V1.0 ");

    go = 'Y';
    while ( go == 'Y') {
        out_crlf();
        out_crlf();
```

```

mess_c("O - output byte to discrete channel\n\r");
mess_c("I - input byte from discrete channel\n\r");
mess_c("A - A/D input routine\n\r");
mess_c("D - D/A output routine\n\r");
mess_c("C - Calibrate analog-buffer card\n\r");
mess_c("E - Exit to monitor ");

ok = 'N';
while ( ok != 'Y') {
    out_crlf();
    mess_c("Enter selection (O,I,A,D,C,E) :");
    c = wait_char();
    if ((c == 'O') | (c == 'I') | (c == 'A') | (c == 'D')) ok = 'Y'
    if ((c == 'C') | (c == 'E')) ok='Y';
}

out_crlf();
switch(c) {
    case 'O' : {
        out_crlf();
        mess_c("Enter discrete channel number (0-2) :");
        ok='N';
        while ( ok != 'Y') {
            chan = in_dec();
            if ((chan <= 2) & (chan >= 0)) ok = 'Y'
            if (ok == 'N') {
                out_char(0x07);
                mess_c("Invalid channel. ");
                mess_c("Try again ");
                out_crlf();
            } /* if */
        } /* while */
        out_crlf();
        ok='N';
        while (ok != 'Y') {
            mess_c("Enter channel ");
            out_int(chan);
            mess_c(" data (0-FF) :");
            data=in_int();
            if ((data >= 0) & (data <= 256)) ok='Y'
        } /* while */
        out_crlf();
        switch (chan) {
            case 0: cio_outa(data);
                break;
            case 1: cio_outb(data);
                break;
            case 2: cio_outc(data);
                break;
            default: break;
        } /* switch */
    }
}

```

```

        out_crlf();
        mess_c("Data (");
        out_int(data);
        mess_c(") present on channel ");
        out_int(chan);
        out_crlf();
        break;
    }

case 'I': {
    out_crlf();
    out_crlf();
    mess_c("Press ESCape to exit ");
    out_crlf();
    out_crlf();
    mess_c("Input discrete data ");
    out_crlf();
    mess_c("b0 b1 b2 b3 b4 b5 b6 b7");
    out_crlf();
    while ((c=in_char()) != 0x1b) {
        data = cio_ina();
        out_char(0x0d);
        j=1;
        while ( j <= 128) {
            k = (j & data);
            if (k ==0) mess_c("0 ");
            if (k !=0) mess_c("1 ");
            j *= 2;
        }
        out_crlf();
        break;
    }

case 'A': {
    out_crlf();
    ok='N';
    while (ok != 'Y') {
        mess_c("Enter channel number (0-23) :");
        chan=in_dec();
        if ((chan <= 23) & (chan >= 0)) ok='Y'
    } /* while */

    out_crlf();
    mess_c("Press ESCape to exit ");
    out_crlf();
    out_crlf();
    mess_c("A/D channel ");
    out_int(chan);
    out_crlf();

```

```

while ((c=in_char()) != 0x1b) {
    point=array;
    ad_in_a(point,1);
    point=array+12;
    ad_in_b(point,1);
    data=array[chan];
    out_char(0x0d);
    out_int(data);
    long2=data;
    out_char(' ');
    fp_out(fdiv(fpconv(long2),con32768));
}
out_crlf();
break;
}

case 'D' : {
    out_crlf();
    ok='N';
    while (ok != 'Y') {
        mess_c("Enter channel number (0-15) :");
        chan=in_dec();
        out_crlf();
        if ((chan >= 0) & (chan <= 15)) ok='Y';
        if (ok == 'N') {
            out_char(0x07);
            mess_c("Invalid channel number");
            mess_c("Try again");
            out_crlf();
        }
    }
    out_crlf();
    out_crlf();
    mess_c("Enter data for channel ");
    out_int(chan);
    mess_c(" :");
    data=in_int();
    array[0]=data;
    point=array;
    da_out(point,chan,1);
    mess_c("Data (");
    out_int(array[0]);
    mess_c(") present on channel ");
    out_int(chan);
    out_crlf();
    break;
}

```

```

case 'C' : {
    while(1) {
        mess_c("\n\n\r");
        mess_c("Analog buffer card calibration\n\n\r");
        mess_c("\n\n\r");
        mess_c("G - select ground\n\n\r");
        mess_c("+ - select plus voltage\n\n\r");
        mess_c("- - select minus voltage\n\n\r");
        mess_c("D - display A/D channels\n\n\r");
        mess_c("M - main menu");
        c = wait_char();
        if (c=='M') break;
        switch (c) {
            case 'G': {
                cio_outa(0x48);
                mess_c("\n\n\rTest mode: Ground\n\n\r");
                break;
            }
            case '+': {
                cio_outa(0x78);
                mess_c("\n\n\rTest mode: Plus\n\n\r");
                break;
            }
            case '-': {
                cio_outa(0x58);
                mess_c("\n\n\rTest mode: Minus\n\n\r");
                break;
            }
            case 'D': {
                mess_c("\n\n\rChannel :");
                i=in_dec();
                if (i > 15) {
                    mess_c("\n\n\rToo big\n\n\r");
                    break;
                }
                if (i < 0) {
                    mess_c("\n\n\rToo small\n\n\r");
                    break;
                }
                mess_c("\n\n\rPress ESCape to exit.\n\n\r");
                while ((c=in_char()) != 0x1b) {
                    point=array;
                    ad_in_a(point,1);
                    point=point+12;
                    ad_in_b(point,1);
                    data=array[i];
                    long2=data;
                    long2=fpconv(long2);
                    long2=fdiv(long2,con32);
                    fp_out(long2);
                    out_char(0x0d);
                } /* while */
                break;
            } /* case 'D' */
        }
    }
}

```

```

        } /* switch */
        } /* while */
    break;
} /* case 'C' */

default: go='N';
} /* switch */
} /* while */
} /* main */

```

Functions defined in inout\_c.s module:

in_char	Assembly routine to check whether a character available in the receive buffer register of the UART from the keyboard. ENTRY: none EXIT: RL0 = 0, if no character was available RL0 = character, otherwise
wait_char	Assembly routine to wait for a character to be available from the keyboard. ENTRY: none EXIT: RL0 = character
out_char	Assembly routine to transmit one character to console port (terminal). ENTRY: RL7 = character to output EXIT: none
out_crlf	Assembly routine to transmit a <CR><LF> to the console port (terminal). ENTRY: none EXIT: none
mess_c	Assembly routine to transmit a sequence of null terminated characters to the console port (terminal). ENTRY: R7 = address of start of string buffer EXIT: none
out_int	Assembly routine to convert a 16-bit integer to ascii-hex and send the characters to the console port (terminal). ENTRY: R7 = 16-bit integer to print EXIT: none
in_int	Assembly routine to accept a 16-bit hex integer constant from the keyboard. The characters are echoed to the console port (terminal) as they input. Any out-of-band characters cause an error message to be displayed and the conversion is again. ENTRY: none EXIT: R2 = 16-bit result

Externals ( NONE )

\_inout\_c MODULE

! RAM ALLOCATION CONSTANTS !

CONSTANT

! SCC REGISTER ADDRESSES !

SCCOA := %FC21

SCCDA := %FC31

GLOBAL

\_in\_char PROCEDURE

ENTRY

! INPUT A CHARACTER FROM THE TERMINAL !

```
TINPUT: INB      RLO,SCCOA      !CHAR RECEIVED?!
        BITB     RLO,#0
        JR       Z,TDONE        !JP IF NOT!
        INB      RLO,SCCDA      !INPUT CHAR!
        RESB     RLO,#7         !CLEAR PARITY BIT!
        LDB      RL2,RLO
        CLRB     RH2
        RET
TDONE:  CLR      R2
        RET
END _in_char
```

\_wait\_char PROCEDURE

ENTRY

! INPUT A CHARACTER FROM THE TERMINAL !

```
TWAIT:  INB      RLO,SCCOA      !CHAR RECEIVED?!
        BITB     RLO,#0
        JR       Z,TWAIT       !JP IF NOT!
        INB      RLO,SCCDA      !INPUT CHAR!
        RESB     RLO,#7         !CLEAR PARITY BIT!
        LDB      RL2,RLO
        CLRB     RH2
        RET
END _wait_char
```



\_out\_char PROCEDURE  
ENTRY

LDB RLO,RL7

! OUTPUT A CHARACTER TO THE TERMINAL !

TOUTCH: PUSH @R15,R1  
LDAR R1,\$+6  
JR TOCHNS  
POP R1,@R15  
RET

! OUTPUT CHARACTER TO TERMINAL WITHOUT USING RAM !

TOCHNS: INB RH0,SCCOA  
BITB RH0,#2  
JR Z,TOCHNS  
TOUT10: OUTB SCCDA,RL0  
JP @R1  
END \_out\_char

\_out\_crlf PROCEDURE  
ENTRY

LDB RLO,'#R'  
CALR TOUTCH  
LDB RLO,'#L'  
JR TOUTCH

END \_out\_crlf

\_mess\_c PROCEDURE

ENTRY

print2: ld r6,@r7  
inc r7,#2  
ldb r11,rh6  
cpb r11,#0  
ret z  
calr print3  
ldb r11,r16  
cpb r11,#0  
ret z  
calr print3  
jp print2  
print3: inb rh0,SCCOA  
bitb rh0,#2  
jr z,print3  
outh SCCDA,r11  
ret  
END \_mess\_c

\_out\_int PROCEDURE

ENTRY

```
    ldb     r11,rh7
    call    out_byte
    ldb     r11,r17
    call    out_byte
    ret
out_byte:
    ldb     r10,r11
    andb    r10,#%0f0
    srlb    r10,#4
    call    out_nib
    ldb     r10,r11
    andb    r10,#%0f
    call    out_nib
    ret
out_nib:
    addb    r10,#%0030
    cpb     r10,#%3a
    jr      c,out_nib2
    addb    r10,#%07
out_nib2:
    inb     rh0,SCCOA
    bitb    rh0,#2
    jr      z,out_nib2
    outb    SCCDA,r10
    ret
END _out_int
```

in\_int PROCEDURE  
ENTRY

! this routine accepts a 16 bit integer (unsigned) from the console !  
! and converts it to binary !

```

ii0:    clr     r8                      ! clear the result registers !
        clr     r9
ii1:    call    _wait_char
        ld      r7,r2                  ! echo character !
        call    _out_char              ! to console !
        cpb     r12,0                 ! was it a CR ? !
        jr      nz,ii2                ! continue if not !
        ld      r2,r8                  ! else, put result in r2 !
        ret                                ! and return !
ii2:    call    atob                   ! convert ascii to binary digi
        jr      c,ii3                  ! go if error !
        sll     r8,#4                  ! shift left 4 places !
        add     r8,r2                  ! add current digit to accumul
        jp      ii1                    ! go for more !
atob:    ldb     rh2,#0                 ! zero top part of r12 !
        cpb     r12,0                 ! make sure not too small !
        jr      c,atob2                ! go if too small !
        cpb     r12,9+1                ! see if alpha offset required
        jr      c,atob3                ! go if not required !
        cpb     r12,A                 ! see if between 9 and A !
        jr      c,atob2                ! go if so !
        cpb     r12,F+1                ! see if > F !
        jr      nc,atob2               ! go if so !
        subb    r12,37                 ! else, subtract alpha offset
        resflg  c                      ! reset error flag !
        ret                                ! and return !
atob2:    setflg  c                     ! indicate error !
        ret                                ! and return !
atob3:    subb    r12,30                 !
        resflg  c
        ret                                ! and return !
ii3:    lda      r7,II4                 ! tell user to try again !
        call    _mess_c                ! print the message !
        jp      ii0

```

END \_in\_int  
II4: ARRAY[\*BYTE]:='?REDO%R%L%00'  
END \_inout\_c

Functions defined in rtc.s module:

**cio\_init**            Assembly routine to initialize the CIO chips w  
are responsible for Real-Time-Clock (RTC) inte  
and discrete (bit) I/O to the Digital Avionics  
interface rack. The three discrete ports on th  
CIO chip are initialized as follows:  
                  PORTA    input\_only  
                  PORTB    input\_only  
                  PORTC    input\_only  
The three ports on the second CIO chip are ini  
as follows:  
                  PORTA    output\_only  
                  PORTB    output\_only  
                  PORTC    output\_only  
(see the CIO chip manual for more information)  
  
ENTRY: none  
EXIT: none

**rtc\_init**            Assembly language routine which is installed a  
interrupt vector for RTC interrupts. The routi  
calls the head\_tracking\_stabilization loop and  
returns. This routine is installed in the PSAP  
the Z8000 as an optional function of CIO\_INIT  
ENTRY: none (interrupt)  
EXIT: none

**cio\_ina**  
**cio\_outa**  
**cio\_inb**  
**cio\_outb**  
**cio\_outc**            Assembly language routines to input-from/output  
the CIO chips. All cio\_inx routines acquire in  
from the first CIO chip, port x. All cio\_outx  
routines send output to the second CIO chip  
  
ENTRY: RL7 = data to output (for output, or  
          none, for input)  
EXIT: RL2 = none (for output, or  
          8-bit data, for input)

Externals ( mess\_c,out\_char,out\_int,out\_crlf,head,Cycle\_Cntr )

# \_cio\_control MODULE

## CONSTANT

```
CIO1      :=      %fd01      ! base address of CIO-1 !
MICR1     :=      %fd01      ! master interrupt control register !
MCCR1     :=      CIO1+2     ! master configuration control register !
CTCSR11   :=      CIO1+20    ! Counter/Timer-1 command and status register
CTCSR12   :=      CIO1+22    !      "      "      2      "      "      "      "
CTMSR11   :=      CIO1+56    ! Counter/Timer-1 mode specification register
CTMSR12   :=      CIO1+58    ! Counter/Timer-2 mode specification register
CTCCR1L1  :=      CIO1+34    ! Counter/Timer-1 current count LSB !
CTCCR1L2  :=      CIO1+38    ! Counter/Timer-2 current count LSB !
CTCCR1H1  :=      CIO1+32    ! Counter/Timer-1 current count MSB !
CTCCR1H2  :=      CIO1+36    ! Counter/Timer-2 current count MSB !
CTTCR1L1  :=      CIO1+46    ! Counter/Timer-1 time constant register LSB !
CTTCR1H1  :=      CIO1+44    ! Counter/Timer-1 time constant register MSB !
CTTCR1L2  :=      CIO1+50    ! Counter/Timer-2 time constant register LSB !
CTTCR1H2  :=      CIO1+48    ! Counter/Timer-2 time constant register MSB !
CTIVR     :=      CIO1+8     ! Counter/Timer-1 interrupt vector register !
```

## ! CIO REGISTER ADDRESSES !

```
IVR1A     :=      %FD05      ! cio 1, port A, interrupt vector register !
IVR1B     :=      %FD07      ! cio 1, port B, interrupt vector register !
IVR1CT     :=      %FD09      ! cio 1, counter/timer interrupt vector regist
DPPR1C     :=      %FD0B      ! cio 1, port C, data path polarity register !
DDR1C      :=      %FD0D      ! cio 1, port C, data direction register !
SIOCR1C    :=      %FD0F      ! cio 1, port C, special I/O register !
PCSR1A     :=      %FD11      ! cio 1, port A, command and status register !
PCSR1B     :=      %FD13      ! cio 1, port B, command and status register !
PDR1A      :=      %FD1B      ! cio 1, port A, data register !
PDR1B      :=      %FD1D      ! cio 1, port B, data register !
PCDR1      :=      %FD1F      ! cio 1, port C, data register !
CVR1       :=      %FD3F      ! cio 1, counter/timer current vector !
PMSR1A     :=      %FD41      ! cio 1, port A, mode specification register !
PHSR1A     :=      %FD43      ! cio 1, port A, handshake specification regis
DPPR1A     :=      %FD45      ! cio 1, port A, data patch polarity register
DDR1A      :=      %FD47      ! cio 1, port A, data direction register !
SIOCR1A    :=      %FD49      ! cio 1, port A, special I/O register !
PMSR1B     :=      %FD51      ! cio 1, port B, mode specification register !
PHSR1B     :=      %FD53      ! cio 1, port B, handshake specification regis
DPPR1B     :=      %FD55      ! cio 1, port B, data path polarity register !
DDR1B      :=      %FD57      ! cio 1, port B, data direction register !
SIOCR1B    :=      %FD59      ! cio 1, port B, special I/O register !
MICR2      :=      %FE01      ! same as CIO-1 (above) !
MCCR2      :=      %FE03
IVR2A      :=      %FE05
IVR2B      :=      %FE07
IVR2CT     :=      %FE09
DPPR2C     :=      %FE0B
DDR2C      :=      %FE0D
SIOCR2C    :=      %FE0F
```

```

PCSR2A := %FE11
PCSR2B := %FE13
PDR2A := %FE1B
PDR2B := %FE1D
PCDR2 := %FE1F
CVR2 := %FE3F
PMSR2A := %FE41
PHSR2A := %FE43
DPPR2A := %FE45
DDR2A := %FE47
SIOCR2A := %FE49
PMSR2B := %FE51
PHSR2B := %FE53
DPPR2B := %FE55
DDR2B := %FE57
SIOCR2B := %FE59

```

#### EXTERNAL

```

_mess_c      PROCEDURE
_out_char    PROCEDURE
_out_int     PROCEDURE
_out_crlf    PROCEDURE
_head        PROCEDURE
_Cycle_Cntr  WORD

```

#### GLOBAL

```

_int_flag    WORD;

```

#### GLOBAL

```

_cio_init PROCEDURE

```

#### ENTRY

```

! on entry r7 contains the desired time constant !

```

```

! first initialize the interrupt stuff !

```

```

di      vi,nvi      ! disable vi,nvi !

ldb      r10,%01     ! do a Cio reset !
. outb    MICR1,r10   ! by setting the reset bit !

ldctl    r1,psapoff  ! current PSAP (should be %FD00) !

add      r1,%1C      ! offset to FCW location !
ld       r0,%4000     ! setup FCW for vectored interrupts !
ld       @r1,r0       ! store %4000 at xx1c in PSAP !

add      r1,%02      ! add to to get next address !
ld       @r1,%_rtc_int ! set vector to our guy !

push     @r15,r7      ! save r7 just in case !
push     @r15,r6      ! save r6 just in case !

```

```

    ldb    r10,#%00      ! set MIE (mast. int. en) !
    outb   MICR1,r10     ! put back out !

    ldb    r10,#%82      ! enable sqr wave, continuous cycle!
    outb   CTMSR11,r10   ! put it back now !
    outb   CTMSR12,r10

    ldb    r10,#00       ! zero the interrupt vector !
    outb   CTIVR,r10     ! of CT-3 CIO-1 !
    pop    r6,@r15       ! get time constant for CT-2 !
    outb   CTTCR1L2,r16  ! set up CTTCR1L2 !
    outb   CTTCR1H2,rh6

    pop    r7,@r15       ! set up time constant for CT-1 !
    outb   CTTCR1L1,r17  ! lsh !
    outb   CTTCR1H1,rh7  ! msh !

    ldb    r10,#%c0      ! set IE for Counter/Timer 2 !
    outb   CTCSR12,r10   ! and same for C/T 2 !

    ldb    r10,#%e0      ! clear IE for C/T 1 !
    outb   CTCSR11,r10

    ldb    r10,#%f7      ! enable (timer-1 clocks timer-2), !
    outb   MCCR1,r10     ! ports A,B, and C of unit 1 !
                      ! using MCCR !

! unit 1 initialization !
! set MSR Port A & B to input single buffer !

    ldb    r10,#%10
    outb   PMSR1A,r10
    outb   PMSR1B,r10

! clear PCSR's, DPPR's, and SIOCR's !

    clr    r0
    outb   PCSR1A,r10
    outb   PCSR1B,r10
    outb   DPPR1A,r10
    outb   DPPR1B,r10
    outb   DPPR1C,r10
    outb   SIOCR1A,r10
    outb   SIOCR1B,r10
    outb   SIOCR1C,r10

! set Data Direction for input !

    ldb    r10,#%ff
    outb   DDR1A,r10
    outb   DDR1B,r10
    outb   DDR1C,r10

```

```

! unit 2 initialization !
! clear the reset bit !

        clr     r0
        outb    MICR2,r10

! set MSR Port A & B to output single buffered !

        ldb     r10,#10
        outb    PMSR2A,r10
        outb    PMSR2B,r10

! clear PCSR's, DPPR's, and SIOCR's !

        clr     r0
        outb    PCSR2A,r10
        outb    PCSR2B,r10
        outb    DPPR2A,r10
        outb    DPPR2B,r10
        outb    DPPR2C,r10
        outb    SIOCR2A,r10
        outb    SIOCR2B,r10
        outb    SIOCR2C,r10

! set Data Direction for output !

        outb    DDR2A,r10
        outb    DDR2B,r10
        outb    DDR2C,r10

! enable ports A, B, & C !

        ldb     r10,#94
        outb    MCCR2,r10

        ldb     r10,#80          ! enable master interrupts !
        outb    MICR1,r10

        ldb     r10,#06
        outb    CTCR11,r10      ! set trigger and gate bits C/T 1!
        outb    CTCR12,r10      ! and C/T 2 !

        ei      vi,nvi
        ret                    ! end of initialization !

END _cio_init

```



\_rtc\_int PROCEDURE

ENTRY

! routine to service the rtc interrupt(s) !

```
        ldm      regs_save,r0,#15          ! save the context at entry !
        ldb      r10,#26                   ! clear IUS,IP bits of C/T 2 !
        outb     CTCsr12,r10
        !        call    _head                not for debug !
        !        inc     _Cycle_Cntr          not for debug !
        ldm      r0,regs_save,#15          ! restore context !
        iredt
        ! return from interrupt !
```

END \_rtc\_int

regs\_save: ARRAY [16 WORD]

\_cio\_ina PROCEDURE

ENTRY

```
! input port A !
        inb      r12,PDR1A
        ret
```

END \_cio\_ina

\_cio\_outa PROCEDURE

ENTRY

```
! output port A !
        outb     PDR2A,r17
        ret
```

END \_cio\_outa

\_cio\_inb PROCEDURE

ENTRY

```
! input port B !
        inb      r12,PDR1B
        ret
```

END \_cio\_inb

```
_cio_outb PROCEDURE
ENTRY
! output port B !
    outb    PDR2B,r17
    ret
END _cio_outb
```

```
_cio_outc PROCEDURE
ENTRY
! output port C !
    outb    PCDR2,r17
    ret
END _cio_outc

END _cio_control
```

# Functions defined in ad\_da.s

```

ad_in_a      Assembly language subroutine to acquire 12 bit
              data from first set of 12 A/D channels. All 12
              channels are converted.
ENTRY:  R7 = address of data buffer (must cont
              at least 24 bytes of free space)
              R6 = 1 if first call, 0 if not
EXIT:  none

ad_in_b      (Same as ad_in_a, except for channels 12-23)

da_out       Assembly language subroutine to output 12-bit
              data to the D/A converter.
ENTRY:  R7 = address of data buffer
              R6 = Start channel (0-15)
              R5 = Number of channels (0-15)
EXIT:  none

```

Externals ( cio\_outc,cio\_outb,cio\_outc )

## \_ad\_da MODULE

### CONSTANT

! A\_D INPUT BASE ADDRESS !

```

BASE1      :=      %f600
BASE2      :=      %f610
CSRL1      :=      BASE1
SCRL1      :=      BASE1+2
MARL1      :=      BASE1+4
DREG1      :=      BASE1+6
CSRL2      :=      BASE2
SCRL2      :=      BASE2+2
MARL2      :=      BASE2+4
DREG2      :=      BASE2+6
RDY        :=      15          ! because of byte swap !
PND        :=      2          ! when doing word I-O !
CAT        :=      1
FST        :=      0

```

! D\_A OUTPUT CHANNEL BASE ADDRESS !

```

BASE       :=      %f710
CHAN0      :=      BASE
CHAN1      :=      BASE+2
CHAN2      :=      BASE+4
CHAN3      :=      BASE+6
CHAN4      :=      BASE+8
CHAN5      :=      BASE+10

```

```

CHAN6 := BASE+12
CHAN7 := BASE+14
BASE3 := %f720
CHAN8 := BASE3
CHAN9 := BASE3+2
CHAN10 := BASE3+4
CHAN11 := BASE3+6
CHAN12 := BASE3+8
CHAN13 := BASE3+10
CHAN14 := BASE3+12
CHAN15 := BASE3+14

```

EXTERNAL

```

_cio_outc    PROCEDURE
_cio_outb    PROCEDURE
_cio_outa    PROCEDURE

```

GLOBAL

\_ad\_in\_a PROCEDURE

ENTRY

```

! r7 has the load address for data (passed from C) !
! r6 has: 1 if start/stop channels are to be updated !
!           0 if start/stop channels have already been initialized !
! check for first time thru !
      ld      r4,r6                      ! init bit !
      cp      r4,#1                      ! 1 means re-init !
      jr      z,ad07                     ! go if init desired !
      in      r1,CSRL1
      bit     r1,#PND
      jr      z,ad37
ad07:  ld      r0,%0010                   ! output init bit to control !
      out     CSRL1,r0
ad10:  in      r1,CSRL1                   ! wait for CAT to clear !
      bit     r1,#CAT
      jr      nz,ad10
      ld      r0,%0100
      out     SCRL1,r0                   ! write 1 to scan !
ad20:  in      r1,CSRL1                   ! wait for CAT to clear !
      bit     r1,#CAT
      jr      nz,ad20
      ld      r0,%0000
      out     SCRL1,r0                   ! write 0 to scan !
ad25:  in      r1,CSRL1                   ! wait for CAT to clear !
      bit     r1,#CAT
      jr      nz,ad25
      ld      r1,%0800
      out     CSRL1,r1                   ! set SCN bit in control !
      ld      r1,%0072
      out     MARL1,r1                   ! set pacer to 100KH !
ad30:  in      r1,CSRL1                   ! wait for scan to clear !
      bit     r1,#CAT
      jr      nz,ad30
      ld      r6,%0b                     ! do all 12 channels !

```

```

ad35:  out      SCRL1,r6
       in       r1,CSRL1           ! wait for CAT to clear !
       bit      r1,#CAT
       jr       nz,ad35
ad37:  ld       r1,#0900           ! set SCN and software trigger
       out      CSRL1,r1
ad40:  in       r1,CSRL1           ! wait for CAT to clear !
       bit      r1,#C      r  z,a! netiocodad4  ld      r2,#0C
       ld       r3,r7           ! start address from C !
ad401: in       r1,CSRL1
       bit      r1,#RDY
       jr       z,ad401
       in       r0,DREG1
       exb      rh0,r10
       ld       @r3,r0
       inc      r3,#2
       djnz     r2,ad401         ! loop till all data read !
       ret
! end of new section !

END _ad_in_a

```

#### \_ad\_in\_b PROCEDURE

##### ENTRY

```

! check for first time thru !
       ld       r4,r6           ! init bit !
       cp       r4,#1           ! see if re-init desired !
       jr       z,ad4f
       in       r1,CSRL2
       bit      r1,#PND
       jr       z,ad77
ad4f:  ld       r0,#0010         ! output INIT bit to control !
       out      CSRL2,r0
ad50:  in       r1,CSRL2         ! wait for CAT to clear !
       bit      r1,#CAT
       jr       nz,ad50
       ld       r0,#0100         ! write 1 to scan !
       out      SCRL2,r0
ad60:  in       r1,CSRL2         ! wait for CAT to clear !
       bit      r1,#CAT
       jr       nz,ad60
       ld       r0,#0000         ! write 0 to scan !
       out      SCRL2,r0
ad65:  in       r1,CSRL2         ! wait for CAT to clear !
       bit      r1,#CAT
       jr       nz,ad65
       ld       r0,#0800         ! set SCN bit in control !
       out      CSRL2,r0
       ld       r1,#0072         ! set pacer to 100KH !
       out      MARL2,r1
ad70:  in       r1,CSRL2         ! wait for CAT to clear !
       bit      r1,#CAT

```

```

        jr      nz,ad70
        ld      r6,#0b
        out     SCRL2,r6
ad75:   in      r1,CSRL2          ! wait for CAT to clear !
        bit     r1,#CAT
        jr      nz,ad75
ad77:   ld      r1,#0900        ! set SCN and software trigger
        out     CSRL2,r1
ad80:   in      r1,CSRL2        ! wait for CAT to clear !
        bit     r1,#CAT
        jr      nz,ad80
! new section !
ad800:  ld      r2,#0c
        ld      r3,r7
ad801:  in      r1,CSRL2
        bit     r1,#RDY
        jr      z,ad801
        in      r0,DREG2
        exb     rh0,r10
        ld      @r3,r0
        inc     r3,#2
        djnz    r2,ad801
        ret
END _ad_in_b          ! end of routine !

```

# da\_out PROCEDURE

## ENTRY

! r7 has the data address, r6 has the start channel, r5 has the # chan

```

daloop: cp      r5,#0          ! see if done !
        ret     z              ! return if done !
        ld      r3,r6          ! next channel number !
        inc     r6,#1
        ld      r2,@r7         ! get next data !
        inc     r7,#2          ! point to next data !
        calr    outda          ! output one word !
        dec     r5,#1          ! decrement channel counter !
        jr      daloop         ! loop till done !

outda:  cp      r3,#3
        jr      gt,doit
        push    @r15,r7        ! save r7 for now !
        ld      r7,#2          ! set write enable of 74LS138 !
        call    _cio_outc
        ld      r7,r3          ! output channel number to cio !
        and     r7,#3          ! only allow channels 0-3 !
        call    _cio_outb
        ld      r7,#3          ! disable 74LS138 !
        call    _cio_outc
        pop     r7,@r15
doit:   sll     r3,#1           ! multiply channel by 2 !
        ld      r4,#f710       ! start address of D/A channels !

```

	add	r4,r3	! add offset to start address !
	exb	rh2,r12	! exchange bytes for output !
	out	@r4,r2	! output the word to the Dig-Analog co
	ret		! end of the routine !
END _da_out			
END _ad_da			

Functions defined in fp\_subs.s module:

All of the below subroutines are used to manipulate floating point data.

-----  
"C"-interface routines

The following routines are directly callable from "C".  
A brief summary of the function and an example syntax  
is given below.

-----

fadd     add two floating\_point numbers  
ex:       fp\_result = fadd(fp1,fp2);

fmul     multiply two floating point numbers  
ex:       fp\_result = fmul(fp1,fp2);

fdiv     divide two floating point numbers (fp1/fp2)  
ex:       fp\_result = fdiv(fp1,fp2);

fcmp     compare two floating point numbers and returns a longw  
result:

comparison	returns
-----	-----
fp1 < fp2	-1
fp1 = fp2	0
fp1 > fp2	1

ex:       long\_result = fcmp(fp1,fp2);

fint     extracts the integer portion of a floating point numbe  
returns the result as a longword integer.  
ex:       long\_result = fint(fp1);

frac     extracts the fractional portion of a floating point nu  
ex:       fp\_result = frac(fp1);

fsub     subtracts two floating point numbers.  
ex:       fp\_result = fsub(fp1,fp2);

fp\_in    allows keyboard input of floating point number. The ro  
accepts standard forms for input (including exponentia  
ex:       fp\_result = fp\_in();

fp\_out   displays a floating point number in non-exponential fo  
ex:       fp\_out(fp1);

fp\_out\_e displays a floating point number in exponential forma

fpconv   converts a long\_integer to floating point representati  
ex:       fp\_result = fpcon(long\_int);



fpcon obtains the floating point equivalent of a character s  
expression.

ex: fp\_result = fpcon("-10.256E-3");

---

#### Assembly-interface routines

The following routines are not directly callable from  
"C". A brief summary of the function is given below.

In each case:

ENTRY:

RR4 = floating point argument 1

RR2 = floating point argument 2 (optional)

EXIT:

RR2 = resulting number (may be floating point  
longword\_integer)

---

fp_add	add	RR2 = RR4+RR2	(fp re
fp_mult	multiply	RR2 = RR2*RR4	(fp re
fp_div	divide	RR2 = RR2/RR4	(fp re
fp_frac	fraction	RR2 = frac(RR2)	(fp re
fp_cmp	compare	RR2 = sgn(RR2-RR4)	(long
fp_int	integer	RR2 = int(RR2)	(long

---

#### Assembly-utility routines

The following routines are not directly callable from  
"C". A brief summary of the function is given below.

---

split	separates the "sign", "exponent", and "mantissa
mul_mant	multiplies two mantissas together
div_mant	divides two mantissas
unsplit	recombines the "sign", "exponent", and "mantiss

Externals ( out\_dec, out\_char, in\_string, out\_crlf, mess\_c, out\_int )

fp\_subs MODULE

EXTERNAL

_out_dec	procedure
_out_char	procedure
_in_string	procedure
_out_crlf	procedure
_mess_c	procedure
_out_int	procedure

GLOBAL

\_fadd PROCEDURE

ENTRY

! C callable procedure to perform floating point addition of !  
! two numbers (must be floating point) and return the result !

! ENTRY:

! rr6 = addend  
! rr4 = additive  
!

! EXIT:

! rr2 = addend + additive

ldl rr2,rr6

call fp\_add

ret

! substitute rr2 for rr6 !  
! which is used in fp\_add !  
! already in rr2 !

END \_fadd

\_fmul PROCEDURE

ENTRY

! C callable procedure to perform floating point multiplicatio  
! of two numbers (must be floating point) and return the resul

! ENTRY:

! rr6 = multiplicand  
! rr4 = multiplier  
!

! EXIT:

! rr2 = multiplicand \* multiplier

ldl rr2,rr6

call fp\_mult

ret

! rr2 for fp\_mult !

END \_fmul

\_fdiv PROCEDURE

ENTRY

! C callable procedure to perform floating point division !  
! of two numbers (must be floating point) and return the resul

! ENTRY:

rr6 = dividend  
rr4 = divisor

EXIT:

rr2 = dividend/divisor

ldl rr2,rr6  
call fp\_div  
ret

END \_fdiv

\_fcmp PROCEDURE

ENTRY

! C callable procedure to compare two floating point numbers !  
! A and B and return either a -1, 0, or a 1 to represent: !  
! A<B, A=B, and A>B, respectively !

! ENTRY:

rr6 = A  
rr4 = B

EXIT:

rr2 = -1,0,1

ldl rr2,rr6  
call fp\_cmp  
ret

END \_fcmp

\_fint PROCEDURE

ENTRY

! C callable routine to return a LONG INTeGer representing !  
! the integer part of a floating point number !

! ENTRY:

rr6 = floating point number of return integer part of

EXIT:

rr2 = integer part of rr6 (not in floating point) !

ldl rr2,rr6  
call fp\_int  
ret

END \_fint

\_frac PROCEDURE

ENTRY

! C callable procedure to return the fractional part of a !  
! floating point number as a floating point number !

! ENTRY:

rr6 = floating point number (input)

EXIT:

rr2 = fractional part of input (floating point format)

ldl rr2,rr6  
call fp\_frac  
ret

END \_frac

\_fsub PROCEDURE

ENTRY

! C callable procedure to perform subtraction on two floating  
! point numbers !

! ENTRY:

rr6 = subtrahend  
rr4 = subtractor

EXIT:

rr2 = subtrahend - subtractor

xor r4, #8000 ! make subtractor negative !  
ldl rr2, rr6  
call fp\_add ! and add to negated subtracto  
ret ! the end !

END \_fsub

fp\_add PROCEDURE

ENTRY

! rr2 contains bit encoded data to add to rr4 !  
! this routine destroys all other register data and returns the  
! result in rr2 !

ldl arg1, rr2 ! save addend !  
ldl arg2, rr4 ! save additive !  
cpl rr2, #0 ! if addend is zero, then !  
jr nz, fpad1 ! return additive, else jump !  
ldl rr2, rr4 ! result is additive if zero !  
ret ! done !

fpad1:  
cpl rr4, #0 ! if additive is zero, then !  
jr nz, fpad2 ! return addend, else jump !  
ret ! additive was zero, so result  
! is already in rr2 !

fpad2:  
call split  
testl arg1 ! test for negative mant !  
jr pl, fpad3 ! go if positive !  
ldl rr6, #0 ! make negative by subtraction  
subl rr6, rr10 ! and move result back into rr  
ldl rr10, rr6 ! done !

```

fpad3:      testl    arg2                ! same as for addend !
            jr      pl,fpad4
            ldl     rr6,#0
            subl    rr6,rr8
            ldl     rr8,rr6

fpad4:      cp      r12,r13              ! while (aexp <> bexp ) ... !
            jr      z,fpad7              ! go if equal !

            jr      gt,fpad5              ! go if aexp > bexp !
            inc     r12,#1                ! increment aexp !
            sral    rr10,#1              ! divide amant by 2 !
            jr      fpad6                ! skip next part !

fpad5:      inc     r13,#1                ! increment bexp !
            sral    rr8,#1                ! bexp = bexp/2 !

fpad6:      jr      fpad4                ! end while.... !

fpad7:      cpl     rr10,#0                ! if one was shifted out !
            jr      nz,fpad8              ! go if amant is not zero !
            ldl     rr2,arg2
            ret

fpad8:      cpl     rr8,#0                ! see if other shifted out !
            jr      nz,fpad9
            ldl     rr2,arg1
            ret

fpad9:      addl    rr8,rr10              ! add mantissas !
            ! now, resulting mantissa is in rr8, resulting exponent in r13

            ld      sign,#0                ! zero negative sign flag !

            testl   rr8                  ! see if mantissa negative !
            jr      pl,fpad10              ! go if positive !
            ldl     rr6,#0                ! else make positive !
            subl    rr6,rr8                ! and put back into rr8 !
            ldl     rr8,rr6                ! done !
            ld      sign,#%ff              ! set negative sign flag !

            ld      r12,sign                ! put sign in r12 for unsplit
            call    unsplit

            ret
END fp_add

```

```

arg1:      wval      0
           wval      0
arg2:      wval      0
           wval      0
sign:      wval      0

```

# split PROCEDURE

## ENTRY

! rr2 is arg 1, rr4 is arg 2 !

```

! results: r12 = exp(arg 1)      from RR2
           r13 = exp(arg 2)      from RR4
           rr10= mant(arg 1)     from RR2
           rr8  = mant(arg 2)     from RR4
           arg1 = rr2
           arg2 = rr4 !

```

```

and      r2, #7f00                ! mask out exponent of arg1!
exb      r12, rh2                 ! place into lower half !
sub      r2, #32                  ! subtract off bias !
ld       r12, r2                  ! save in r12 !

and      r4, #7f00                ! mask out exponent of arg2 !
exb      r14, rh4                 ! place into lower half !
sub      r4, #32                  ! subtract off bias !
ld       r13, r4                  ! save in r13 !

ldl      rr2, arg1                ! get uncorrupted arg1 back !
and      r2, #7ff                 ! only need lower 8 bits !
or       r2, #100                 ! set hidden bit !
ldl      rr10, rr2                ! save arg2 mant in rr10 !

ldl      rr4, arg2                ! same as above !
and      r4, #7ff
or       r4, #100
ldl      rr8, rr4                 ! save additive mant in rr8 !

```

```

           ret
END split

```

GLOBAL

fp\_mult PROCEDURE

ENTRY

! rr2 contains bit encoded data to multiply !  
! by rr4. This routine destroys all other register !  
! data and returns the answer in rr2. !

```
        ld1    arg1,rr2          ! save multiplicand !
        ld1    arg2,rr4          ! save multiplier !

        cpl    rr2,#0            ! if zero then !

        jr     nz,fpmul1         ! return zero, else jump !
        ld1    rr2,#0            ! result is zero !
        ret                                ! done !

fpmul1:
        cpl    rr4,#0            ! if zero then !

        jr     nz,fpmul2         ! return zero else jump !
        ld1    rr2,#0            ! result is zero !
        ret                                ! done !

fpmul2:
        call   split              ! mask out exp' and mant' !
! r13 is exp and rr10 is mant of multiplicand !
! r12 is exp and rr8 is mant of multiplier !

        cpl    rr8,#0            ! if zero then !

        jr     nz,fpmul3         ! return zero, else jump !
        ld1    rr2,#0            ! result is zero !
        ret                                ! done !

fpmul3:
        cpl    rr10,#0           ! if zero then !

        jr     nz,fpmul4         ! return zero, else jump !
        ld1    rr2,#0            ! result is zero !
        ret                                ! done !

fpmul4:
        ld1    rr4,rr8           ! set up to multiply the !
        ld1    rr6,rr10          ! mantissi together !
        call   _mul_mant         ! returns result in rr2 !

        ld     sign,#0           ! start test for sign !
        testl  arg1              ! check to see if !
        jr     lt,fpmul5         ! result is positive or !
        testl  arg2              ! and set sign bit !
        jr     lt,fpmul6         ! accordingly !
```



```

fpmul5:   jr      fpmul7                      ! positive !
          testl   arg2
          jr      gt,fpmul6
          jr      fpmul7                      ! positive !
fpmul6:   ld      sign,%ff                    ! negative !
fpmul7:
          ld1     rr8,rr2                     ! setup to call unstrip !
          add     r13,r12                     ! resulting mantissa in rr8 !
          ld      r12,sign                    ! sum of exp in r13 !
          call    unsplit                     ! sign in r12, 0 if pos, ff if
          ret                                           ! reforms the product into !
          ret                                           ! a 32 bit fp number !
          ret                                           ! done !

```

END fp\_mult

GLOBAL

\_mul\_mant PROCEDURE

ENTRY

```

          slal    rr6,#6
          slal    rr4,#6
          ld1     rr2,rr4
          multl   rq4,rr2
          sral    rr4,#4
          ld1     rr2,rr4
          ret
END _mul_mant

```

\_div\_mant PROCEDURE

ENTRY

```

          ld1     rr2,rr4
          ld1     rr4,rr6
          ld1     rr6,#0
          divl    rq4,rr2
          ld1     rr2,rr6
          srl1    rr2,#8
          ret
END _div_mant

```

GLOBAL

unsplit PROCEDURE

ENTRY

! enter this routine with cmantissa in rr8 and cexp in r13 !  
! sign in r12 , 0 if pos and ff if neg !  
! returns result in rr2 !

```
fpad10:      ld      r0,#0                ! i = 0!
              ld1     rr2,#0
              testl   rr8                ! already done if zero !
              ret     z

fpad11:      ld1     rr2,rr8              ! rr2 is cmant !
              and     r2,#fff0           ! keep only upper bits !
              clr     r3
              cpl     rr2,#1000000       ! (see if normalized) !
              jr      z,fpad14           ! go if equal to 01000000 !
              cp      r0,#32             ! make sure r0 not equal to 32
              jr      z,fpad14           ! else leave the loop !
              cpl     rr8,#1000000       ! see if bigger or smaller !
              jr      lt,fpad12          ! go if smaller !

              sral    rr8,#1              ! divide mantissa !
              inc     r13                 ! and add one to exponent !
              jr      fpad13             ! skip next part !

fpad12:      slal    rr8,#1              ! multiply mantissa by 2 !
              dec     r13                 ! and subtract one from expone

fpad13:      inc     r0                  ! add one to r0 !
              jr      fpad11             ! loop till normalized !

fpad14:      cp      r13,#-31            ! see if underflow !
              jr      gt,fpad15          ! go if not !
              ld1     rr2,#0             ! else, underflow error !
              ret

fpad15:      cp      r13,#31             ! see if overflow !
              jr      lt,fpad17          ! go if not !
              ld1     rr8,#3effffff      ! else is, and gets max value

              cp      r12,#ff            ! see if negative !
              jr      nz,fpad16          ! go if positive !
              or      r8,#8000           ! else, set sign bit !

fpad16:      ld1     rr2,rr8              ! return with limited result !
              ret

fpad17:      ld1     rr2,rr8              ! get mantissa into rr2 !
```

```

        and      r2, #00ff          ! clear exponent part !
        cp       r12, #fff          ! see if negative !
        jr       nz, fpad18         ! go if positive !

        or       r2, #8000          ! or in sign bit !
fpad18: add      r13, #32            ! add bias to exponent !
        ld       r4, r13
        exb      rh4, rl4
        ld       r13, r4
        or       r2, r13            ! now, word is complete !
        ret
END unsplit

```

GLOBAL

fp\_div PROCEDURE

ENTRY

```

! rr2 contains bit encoded data to divide by rr4. !
! this routine destroys all other register data !
! and returns the answer in rr2 . !

```

```

        ex       r3, r5
        ex       r2, r4
        ld1      arg1, rr2          ! save dividend !
        ld1      arg2, rr4          ! save divisor !

        cpl      rr4, #0            ! if zero then, !
        jr       nz, fpdiv1         ! return zero, else jump !
        ld1      rr2, #0            ! result is zero !
        ret                          ! done !

```

```

fpdiv1: cpl      rr2, #0            ! if zero then, !
        jr       nz, fpdiv2         ! return max, else jump !
        ld1      rr2, #3effffff     ! result is max !
        ret                          ! done !

```

```

fpdiv2: call split                  ! mask out exp' and mant' !

```

```

! r13 is exp and rr10 is mant of divisor !
! r12 is exp and rr8 is mant of dividend !

```

```

        cpl      rr10, #0           ! if zero then !
        jr       nz, fpdiv3         ! return max, else jump !
        ld1      rr2, #3effffff     ! result is max !
        ret                          ! pdi cpl rr8, #0
        jr       nz, fpdiv4         ! return zero, else jump !

```

```

        ldl      rr2,#0          ! result is zero !
        ret                               ! done !

fpdiv4:
        cpl      rr8,rr10        !for mant div !
        jr      lt,fpdiv5        ! if dividend => divisor then,
        sral     rr8,#1          ! divide dividend man by 2 !
        inc      r13,#1          ! bump up the exp !
        jr      fpdiv4          ! try till true !

fpdiv5:
        ldl      rr6,rr8         ! set up to divide the mant !
        ldl      rr4,rr10        ! by one another !
        call     _div_mant       ! returns result in rr2 !

        ld       sign,#0        ! start test for sign !

        testl    arg1           ! check to see if !
        jr      lt,fpdiv6       !result is positive !
        testl    arg2           ! or neg and set sign flag !
        jr      lt,fpdiv7       ! accordingly !
        jr      fpdiv8

fpdiv6:
        testl    arg2
        jr      gt,fpdiv7
        jr      fpdiv8

fpdiv7:
        ld       sign,#1ff      ! neg !

fpdiv8:
        ldl      rr8,rr2         ! set up for unsplit !
        sub      r13,r12        ! subtract exponents !
        nop
        ld       r12,sign       ! still setting up for unsplit
        call     unsplit        ! result in rr2 !
        ret
END fp_div

```

# fp\_int PROCEDURE

## ENTRY

```

! rr2 contains number to return integer part of in rr2 !
      ld1    arg1,rr2      ! save off argument !
      call   split        ! resulting mantissa in rr10,

      ld      sign,#0      ! determine the sign !
      testl   arg1
      jr      pl,fpint1    ! go if positive !
      ld      sign,#%ff    ! else, flag as negative !
fpint1:
      cp      r12,#0      ! if exp < 0, then int(arg1)=0
      jr      ge,fpint2    ! go if exp > 0 !
      ld1     rr2,#0      ! else, result is zero !
      ret

fpint2:
      cp      r12,#31      ! if exp > 31 then overflow !
      jr      le,fpint3    ! go if no overflow !
      ld1     rr2,%7ffffff ! rr2 gets max positive value
      cp      sign,%ff     ! see if sign < 0 !
      ret     nz           ! done if positive !
      addl    rr2,#1       ! else make max negative %8000
      ret             ! and return !

fpint3:
      ld1     rr2,#0      ! zero accumulator !

fpint4:
      cp      r12,#0      ! while exp >= 0 !
      jr      lt,fpint6    ! go if exp < 0 !

      addl    rr2,rr2      ! double accum !
      bit     r10,#8       ! check bit of mant !
      jr      z,fpint5     ! go if bit is zero !
      addl    rr2,#1       ! increment accum !

fpint5:
      and     r10,%ff      ! clear bit !
      addl    rr10,rr10    ! double mant !
      dec     r12,#1       ! decrement exp !
      jr      fpint4       ! loop while... !

fpint6:
      cp      sign,%ff     ! if sign <> 0 !
      jr      nz,fpint7    ! then, negate result !
      ld1     rr8,#0       ! use rr8 !
      subl    rr8,rr2      ! make neg !
      ex      r2,r8
      ex      r3,r9        ! now result in rr2 !

fpint7:
      ret                ! end of fp_int !
END fp_int

```

# fp\_frac PROCEDURE

ENTRY

```

! rr2 is fp number input, rr2 is fp fractional output !
ldl    arg1,rr2
testl  rr2
jr     nz,fpfrc1      ! go if input is non zero !
ldl    rr2,#0         ! else, return zero as result
ret

fpfrc1:
call   split          ! rr10 is mant, r12 is exp !
cp     r12,#-1        ! if exp <= -1 then already a
jr     gt,fpfrc2      ! go if > -1 !
ldl    rr2,arg1       ! already fraction!
ret

fpfrc2:
cp     r12,#-1        ! while exp > -1 ... !
jr     le,fpfrc3      ! go if exp <= -1 !
dec    r12,#1         ! exp = exp -1 !
addl   rr10,rr10      ! multiply mant by 2 !
jr     fpfrc2         ! end while !

fpfrc3:
and    r10,#%01fff    ! mask out stuff > 1 in mant !
ld     sign,#0
cp     arg1,#0        ! see if < 0 !
jr     ge,fpfrc4      ! go if >= 0 !
ld     sign,#%fff     ! else, flag as < 0 !

fpfrc4:
ldl    rr8,rr10       ! setup for unsplit !
ld     r13,r12        ! ... !
ld     r12,sign       ! ... !
call   unsplit
ret
! end of fp_frac !
END fp_frac

```

# \_fp\_out PROCEDURE

## ENTRY

```
ldl rr2,rr6 ! copy C variable to rr2 !
! rr2 has fp number of output !
ldl arg1,rr2 ! save off !
call split ! rr10 has mant, r12 has exp !

testl arg1 ! see if number < 0 !
jr ge,fpout1 ! go if >= 0 !
ldb r17,#%2d ! '-' sign !
call _out_char ! assembly routine !
ldl rr2,arg1 ! get rr2 back and clear sign
res r2,#15 ! clear the sign bit !
ldl arg1,rr2 ! back in arg1 okay !

fpout1:
ldl rr2,arg1 ! get arg1 back !
call fp_int ! get integer part back !
pushl @r15,rr2 ! save on stack !
ldl rr2,arg1 ! get arg1 back !
call fp_frac ! get fractional part back !
popl rr6,@r15 ! get integer back into rr6 !
pushl @r15,rr2 ! save rr2 !
call _out_dec ! 'C' routine to output integer
ldb r17,#%2e ! '.' !
call _out_char ! output it to CRT !

popl rr2,@r15 ! get rr2 back !

ld dig_count,#0 ! digit counter !

fpout2:
testl rr2 ! stop if goes to zero !
jr z,fpout3 ! go if fractional goes to zero

cp dig_count,#05 ! stop after 6 digits !
jr gt,fpout3 ! stop if 6 done already !
inc dig_count

ldl rr4,#%23400000 ! the number 10 !
call fp_mult ! result in rr2 !
pushl @r15,rr2 ! save result of mult !
call fp_int ! get integer part (0-9) !
ldb r17,r13 ! output as digit !
addb r17,#%30 ! ascii offset !
call _out_char ! output to screen !
popl rr2,@r15 ! get rr2 back !
call fp_frac ! result in rr2 !
jr fpout2 ! loop till done !

fpout3:
ret ! end of fp_out !
END _fp_out
```

```

dig_count:
    wval    0

fp_cmp PROCEDURE

ENTRY
    ! rr2 is compared with rr4, returns -1,0,1 for <,> !
    ld1     arg1,rr2          ! save args !
    ld1     arg2,rr4          ! ... !
    call    split             ! rr10,r12 is mant,exp arg1 !
                                ! rr8 ,r13 is mant,exp arg2 !
                                ! get args back !
    ld1     rr2,arg1          ! done !
    ld1     rr4,arg2
    and     r2,#%8000         ! mask sign bit !
    and     r4,#%8000         ! of both arguments !
    sub     r2,r4             ! sgn(arg1) - sgn(arg2) !
    jr      eq,fpcmp1         ! go if same sign !
    jr      gt,fpcmp3         ! arg2 < arg1 !
    jr      fpcmp2           ! arg1 < arg2 !

fpcmp1:
    cp      r12,r13           ! compare the exponents !
    jr      eq,fpcmp4         ! go if equal !
    jr      gt,fpcmp6         ! go if exp(arg1) > exp(arg2)
    jr      fpcmp7           ! go if arg1 < arg2 !

fpcmp2:
    ld1     rr2,#-1           ! arg1 < arg2 !
    ret

fpcmp3:
    ld1     rr2,#1            ! arg1 > arg2 !
    ret

fpcmp4:
    subl    rr10,rr8          ! exponents same, test mantiss
    jr      eq,fpcmp5         ! equal !
    jr      gt,fpcmp6         ! arg1 > arg2 !
    jr      fpcmp7           ! arg1 < arg2 !

fpcmp5:
    ld1     rr2,#0            ! equal !
    ret

fpcmp6:
    ld1     rr2,#1
    jr      fpcmp8

fpcmp7:
    ld1     rr2,#-1

fpcmp8:
    testl   arg1              ! if args < 0 , complement res
    ret
    testl   rr2              ! ok if arg is zero !
    ret
    jr      gt,fpcmp2         ! else change 1 to -1, visa-ve
    jr      fpcmp3

END fp_cmp

```



# fp\_in PROCEDURE

## ENTRY

```
! gets characters into array, converts to real in rr2 !
ld      r7,#string      ! address of string storage !
ld      r6,#20           ! num characters !
call    _in_string      ! get chars !
fp_in_con:
ld      mult_factor,%%2000      ! 1.0 !
ld      mult_factor+2,%%0000

ld      point,#0           ! dec point not encountered !
ld      ntor,#0           ! number of digits to right of
ldl     rr2,#0            ! zero result !
ld      r14,#string       ! string pointer !
ld      in_sign,#0        ! sign is positive !

fpin1:
testb   @r14              ! while still more chars !
jp      z,fpin7           ! go if done !
ldb     r10,@r14          ! get next character !
cpb     r10,%%2e          ! see if '.' !
jp      nz,fpin2          ! go if not !
ld      point,#1         ! else flag point !

fpin2:
cpb     r10,#'-'         ! see if '-' !
jp      nz,fpin25        ! go if not a '-' !
ld      in_sign,#1       ! else, flag as < 0 !

fpin25:
cpb     r10,#'E'         ! see if exponent next !
jr      nz,fpin3         ! go if not !
jp      fpin8            ! else, it is, so process !

fpin3:
cpb     r10,#'9'         ! make sure a valid character
jp      gt,fpin45        ! go if too big !
cpb     r10,#'0'         ! go if too small !
jp      lt,fpin45

test     point           ! see if to right of '.' !
jp      z,fpin4          ! go if not to right yet !

fpin4:
test     point           ! don't mult by 10 if '.' found
jp      nz,fpin40        ! go if '.' already found !
push     @r15,r0         ! save character !
ldl     rr4,%%23400000   ! constant : 10 !
call     fp_mult         ! 10 * result !
pop      r0,@r15        ! get character back !

fpin40:
subb     r10,%%30        ! subtract ascii bias !
ldb      rh0,#0         ! zero upper half or r0 !
add      r0,r0          ! double result !
! for indexing into contab !
```

```

        add    r0,r0                ! double again (4 bytes each)
        ld     r1,r0                ! transfer to r1 for indexing
        ld1    rr4,contab(r1)       ! get constant !

! now, rr2 is the running result
!   rr4 is the digit just typed in
!
        pushl   @r15,rr2            ! save rr2 temporarily !

! save running result !

        ld1     rr2,mult_factor      ! get mutiplication factor !
        test    z,fpin41             ! if dp found, divide by 10 an
        jr      z,fpin41             ! go if no point found yet !

        pushl   @r15,rr4            ! else, save rr4 !
        ld1     rr4,0x23400000       ! divide mult_factor by 10 !
        call    fp_div               ! do the divide !
        ld1     mult_factor,rr2      ! new one stored off !
        popl    rr4,@r15            ! get back digit constant !

fpin41:  ld1     rr2,mult_factor      ! get new mult_factor !

        call    fp_mult              ! multiply digit const by mult
        popl    rr4,@r15            ! get what was rr2 back (resul
        call    fp_add               ! add result to digit*mult_fac

fpin45:  inc     r14                 ! bump character pointer !
        jp      fpin1               ! loop till done !

fpin7:   test    in_sign             ! see if < 0 !
        ret     z                   ! finished if not < 0 !

        or      r2,0x8000           ! else, set sign bit !
        ret                                ! before returning !

fpin8:   ! here if 'E' was found in input, indicating exponential notat
        pushl   @r15,rr2            ! save base10 mantissa on stac
        inc     r14                 ! but first bump char pointer
        ld      r2,in_sign          ! get in_sign !
        ld      r3,point            ! and point !
        pushl   @r15,rr2            ! and save on stack !
        ld1     rr2,mult_factor      ! get mult_factor !
        pushl   @r15,rr2            ! and save on stack !
        ld      in_sign,#0          ! zero out in_sign and point !
        ld      point,#0            ! so exponent value will be co
        ld1     rr2,0x20000000       ! back to original mult_factor
        ld1     mult_factor,rr2
        ld1     rr2,#0              ! zero out accumulator !

```

```

call    fpin1
ldl     rr6,rr2
call    _fint
ldl     rr4,rr2
! this is recursive !
! only the integer part counts
! result in rr2 (should be onl
! put result into rr4 !

popl    rr2,@r15
ldl     mult_factor,rr2
! mult_factor is back into rr2
! store back off !

popl    rr2,@r15
ld      in_sign,r2
ld      point,r3
! r2 = in_sign, r3 = point !

popl    rr2,@r15
! rr2 has mantissa again !

fpin9:  testl   rr4
jr      z,fpin7
! see if exponent gone to zero
! go if done !

jr      gt,fpin10
! go if exp > 0 !

addl    rr4,#1
pushl   @r15,rr4
ldl     rr4,%%23400000
! increment exponent !
! save exponent on stack !
call    fp_div
! divide result by 10 !
popl    rr4,@r15
! after adjusting exponent upw
jr      fpin9
! and loop !

fpin10: subl    rr4,#1
pushl   @r15,rr4
ldl     rr4,%%23400000
! decrement exponent !
! save exponent on stack !
call    fp_mult
! multiply by 10 !
popl    rr4,@r15
! after adjusting exponent dow
jr      fpin9
! and loop !

END _fp_in

```

```

point:
    wval    0
ntor:
    wval    0
in_sign:
    wval    0
string:
    array   [25 word]
spaces:
    array   [*byte] := ' '
    wval    %0000
savel:
    array   [20 word]
contab:
    wval    %0000                ! 0.0 !
    wval    %0000
    wval    %2000                ! 1.0 !
    wval    %0000
    wval    %2100                ! 2.0 !
    wval    %0000
    wval    %2180                ! 3.0 !
    wval    %0000
    wval    %2200                ! 4.0 !
    wval    %0000
    wval    %2240                ! 5.0 !
    wval    %0000
    wval    %2280                ! 6.0 !
    wval    %0000
    wval    %22c0                ! 7.0 !
    wval    %0000
    wval    %2300                ! 8.0 !
    wval    %0000
    wval    %2320                ! 9.0 !
    wval    %0000
mult_factor:
    wval    %0000
    wval    %0000

```

# \_fpcon PROCEDURE

## ENTRY

```
! C callable procedure to convert a character constant !
! floating point number into an actual floating point number !
! usage:
!     fp_number = fpcon("3.14159");

fpcon1:  ld      r4,#string          ! address of string area !
        ldb     r10,@r7            ! copy characters into string
        ldb     @r4,r10            ! area used by fpin !
        inc     r7                 ! move one !
        inc     r4
        cpb     r10,#0             ! see if done !
        jr      nz,fpcon1          ! loop till done (0 found) !

        call    fp_in_con          ! go do it !
        ret     the end !
END _fpcon
```

# \_fp\_out\_e PROCEDURE

## ENTRY

! procedure to printout the variable in rr6 in exponential (base 10)

```
ld      exp10,#0                  ! base ten exponent is zero fi

ldl     rr2,#0
cpl     rr6,#0
jr      z,fpoe1                  ! go if argument is a zero !

ldl     temp1,rr6                 ! save argument !
res     r6,#15                   ! clear sign bit for compare !
ldl     rr4,#%20000000            ! constant 1.00 !
call    _fcmp                    ! rr2 = -1,0,1 if <1,=1,>1 !
testl   rr2                      ! check sign of comparison !
jp      lt,fpoe2                 ! go if < 1 !

ldl     rr6,temp1                ! see if > 9 !
res     r6,#15
ldl     rr4,#%23200000            ! constant 9.00 !
call    _fcmp                    ! same return status as above
testl   rr2                      ! check sign of comparison !
jp      gt,fpoe3                 ! go if > 9 !

ldl     rr2,temp1
```

```

fpoe1:      ld1      rr6,rr2          ! print mantissa part !
            call     _fp_out
            ldb      r17,#'E'        ! print 'E' !
            call     _out_char
            ld       r7,exp10        ! load exp10 into rr6 !
            exts     rr6              ! extend sign !
            test     r6               ! see if >= 0 !
            jr       lt,fpoe11       ! go if < 0 !
            pushl    @r15,rr6
            ldb      r17,#'+'        ! else, print '+' !
            call     _out_char
            popl     rr6,@r15

fpoe11:     call     _out_dec          ! output the exponent !
            ld1      rr2,#1           ! return 1 !
            ret

fpoe2:      ! rr7 < 1.0 !
            ld1      rr2,temp1        ! get argument !

fpoe22:     pushl    @r15,rr2          ! save result !
            ld1      rr6,rr2          ! compare with 1.0 again !
            res      r6,#15           ! clear sign bit !
            ld1      rr4,%%20000000   ! 1.0 constant !
            call     _fcmp
            testl    rr2              ! check sign of result !
            popl     rr2,@r15         ! get result back !
            jp       ge,fpoe1         ! already ready for output !

            ld1      rr4,%%23400000   ! multiply by 10 !
            call     fp_mult
            dec      exp10            ! and decrement exponent !
            jr       fpoe22          ! loop till done !

fpoe3:      ! rr7 > 9.0 !
            ld1      rr2,temp1

fpoe33:     pushl    @r15,rr2          ! save result !
            ld1      rr6,rr2          ! compare with 9.0 again !
            res      r6,#15           ! clear sign bit !
            ld1      rr4,%%23200000   ! 9.0 constant !
            call     _fcmp
            testl    rr2              ! check sign of result !
            popl     rr2,@r15         ! get result back !
            jp       le,fpoe1         ! already ready for output !

            ld1      rr4,%%23400000   ! multiply by 10.0 !
            call     fp_div
            inc      exp10            ! and increment exponent !
            jr       fpoe33          ! loop till ready to print !

END _fp_out
temp1:      wval     %0000
            wval     %0000

```

```

expl0:  wval    %0000
        wval    %0000

```

```

_fpconv PROCEDURE

```

```

ENTRY

```

```

    ! converts long integer in rr6 to fp number in rr2 !

```

```

        ld1     rr8,rr6                ! setup for call to unsplit !
        ld      r12,#0                 ! make positive, default !
        testl   rr8                    ! if negative, make pos, set s
        jr      ge,fpconv1             ! go if pos !
        ld1     rr2,#0
        subl    rr2,rr8                 ! else, make positive !
        ld1     rr8,rr2
        ld      r12,%ff                ! and flag as negative !
fpconv1:
        ld      r13,#24                 ! original exponent is 12 !
        jp      unsplit                ! normalize and return !

```

```

END _fpconv

```

```

END fp_subs

```

APPENDIX B

ADDISP



```

/* program to input and display data from the A/D board */
/* external references */

extern int in_char(), in_int(), wait_char(), out_int(), mess_c();
extern int ad_in_a(), ad_in_b();
int ch_array[8], count2;
int adin[30], *pointer;

/* local variables */
int num_chans, count;
char con_dis, c, cntrl;

main ()
{
    out_crlf();
    mess_c("A/D input and display program ");
    out_crlf();
    out_crlf();
    mess_c("Display how many channels (0-7) :");
    num_chans = in_int();
    if (num_chans != 0) {
        if (num_chans > 7) num_chans = 7;
        out_crlf();
        mess_c("Number of channels set to:");
        out_int(num_chans);
        out_crlf();
        for (count=1; count<=num_chans; count++) {
            mess_c("column");
            out_int(count);
            mess_c(" ");
            ch_array[count]=in_int();
            out_crlf();
        } /* for */
        out_crlf();
        mess_c("Continuout or Discrete sampling (C/D) :");
        con_dis=wait_char();
        if ((con_dis != 'C') & (con_dis != 'D')) con_dis = 'D';
        out_crlf();
        mess_c("Sampling set to :");
        out_char(con_dis);
        out_crlf();
        /* the following is the main routine */

        c=count2=0;
        while (((cntrl=in_char()) != 0x1B & c != 0x1B)) {
            if ((cntrl=='C') | (c=='C')) con_dis = 'C';
            if ((cntrl=='D') | (c=='D')) con_dis = 'D';
            if (count2==15) { /* redisplay channel numbers */
                out_crlf();
                for (count=1; count<=num_chans; count++) {
                    mess_c("chan:");
                    out_int(ch_array[count]);
                    mess_c(" ");
                } /* for */
            }
        }
    }
}

```

```

        out_clrf();
        for (count=1;count<=num_chans;count++)
            mess_c("-----");
        out_clrf();
        out_clrf();
        count2=0;
        } /* if */
count2++;
pointer = adin;
ad_in_a(pointer,12,1);
pointer=adin+12;
ad_in_b(pointer,12,1);
for (count=1;count<=num_chans;count++) {
    out_int(adin[ch_array[count]]);
    mess_c(" ");
} /* for */
out_clrf();
if ((cntrl=='P') | (con_dis == 'D')) {
    mess_c("--PAUSED--");
    c=wait_char();
    out_clrf();
} /* if */
} /* while */
} /* if */
/* main */ }

```

APPENDIX C

DARAMP

```

/*
** Routine to output a ramp to the D/A's
*/

extern int    in_char(),out_crlf(),in_int(),mess_c(),da_out();
extern int    cio_unit();
int          start_chan,stop_chan,i,chan,num_chans;
int          ch_array[20],j,data_array[1],*k;
int          start_count,stop_count,delta_count;
char         c,d;

main()
{
    cio_unit();
    out_crlf();
    mess_c("D/A ramp program ");
    out_crlf();

    mess_c("Input start count :");
    start_count=in_int();
    out_crlf();

    mess_c("Input stop count  :");
    stop_count=in_int();
    out_crlf();

    mess_c("Input delta count :");
    delta_count=in_int();
    out_crlf();

    /* get the channel definitions */

    mess_c("Output to how many channels ? (1-10 hex) ");
    num_chans=in_int();

    if (num_chans > 16)
        num_chans=16;

    if (num_chans < 1 )
        num_chans=1;
    out_crlf();

    for(j=0; j<=(num_chans-1); j++)
    {
        mess_c("Enter channel number :");
        ch_array[j]=in_int();
        out_crlf();
    }

    for(j=0; j<=15; j++)
    {
        data_array[0]=0;
        da_out(data_array,j,1);
    }
}

```

```

    }

    /* main routine follows */

    mess_c("starting ramp ");
    out_crlf();

    while( ((c=in_char())!=0x1b) & (d!=0x1b) )
    {
        for(i=start_count; i<=stop_count; i+=delta_count)
        {
            for(j=0 ; j<=(num_chans-1) ; j++)
            {
                da_out(data_array,ch_array[j],1);
                data_array[0]=i;
                d=in_char();
            }
        }
    }

} /* MAIN() */

```

APPENDIX D

ADTODA

```

/*
** ad_to_da.c :
**           program to routine an A/D channel
**           to a D/A channel
**
extern int  da_out(),ad_in(),mess_c(),in_char(),out_crlf(),in_int();
extern int  out_int(),out_char();
          int  da_chan,ad_chan,adin[30];
          char c,d;

main()
{
    out_crlf();
    mess_c("A/D to D/A routing program ");
    out_crlf();
    out_crlf();

    mess_c("A/D channel number :");
    ad_chan = in_int();
    out_crlf();

    mess_c("D/A channel number :");
    da_chan = in_int();
    out_crlf();

    if( da_chan>15 )
        da_chan = 15;

    mess_c("Routing started :");
    out_crlf();
    out_crlf();

    while( (c=in_char())!=0x1b )
    {
        ad_in(adin);
        da_out(da_chan,adin[ad_chan]);
    }

    out_crlf();
    out_crlf();
} /* MAIN() */

```

APPENDIX E

DSCOUT



```

/*
** Program to test the discrete output
**
*/

extern int    in_char(),out_int(),mess_c(),out_crlf();
extern int    cio_unit(),cio_outa();
int         b,i;
char        c;

main()
{
    cio_unit();
    mess_c("Discrete output test routine ");
    out_crlf();
    out_crlf();
    mess_c("Starting sequence ");
    out_crlf();
    while( (c=in_char())!=0x1b)
    {
        b = 1;
        while( (b<=128) & ((c=in_char())!=0x1b) )
        {
            cio_outa(b);
            b *= 2;
            for(i=0; i<=32766; i++)
                ; /* delay */
        }
        /* now blink and invert */
        b = 1;
        while( (b<=128) & ((cin=in_char())!=0x1b) )
        {
            i = b^0xff;
            cio_outa(i);
            b *= 2;
            for(i=0; i<=32766; i++)
                ; /* delay */
        }
    }
} /* MAIN() */

```

APPENDIX F

ACTIVITY

```

/* routine to check out the activity circuitry */

extern int cio_init(),cio_outb(),cio_outc(),mess_c(),out_crlf();
int i,j,k,data[3],*point;
char c,d,e;

main()
{
    cio_init();
    out_crlf();
    mess_c("Starting activity test...");
    out_crlf();
    for (j=0; j<=3; j++)
    {
        mess_c("D/A channel ");
        out_int(j);
        mess_c(" test");
        out_crlf();
        for (i=0; i<=16384; i++)
        {
            data[0]=0x4000;
            point= data;
            da_out(point,j,1); /* address=point, channel=j, data's=1 */
        }
    }

    out_crlf();
    mess_c("All channels ");
    out_crlf();

    while (1)
    {
        for (i=0; i <= 32766; i++)
        {
            c = in_char();
            j = 0;
            point = data;
            da_out(point,j,4);

            if( c==0x1b )
                break;
        }

        if( c==0x1b )
            break;
    }

    /* reset all the activity lights */
} /* main */

```

# DISTRIBUTION

	<u>No. of Copies</u>
University of Alabama in Huntsville Off Campus Research Facility ATTN: AMSMI-RD-SS-SE, Bldg 5400	10
US Army Materiel System Analysis Activity ATTN: AMXSY-MP Aberdeen Proving Ground, MD 21005	1
ITT Research Institute ATTN: GACIAC 10 W. 35th Street Chicago, IL 60616	1
AMSMI-RD, Dr. McCorkle	1
Dr. Rhoades	1
AMSMI-RD-CS-R	15
AMSMI-RD-CS-T	1
AMSMI-RD-SS-SE, Dr. Hallum	1
AMSMI-GC-IP, Mr. Bush	1

END

6-87

DTIC